Brookhaven National Laboratory RADIOLOGICAL WORK PERMIT

RWP # <u>06-03</u> Start Date: <u>08-01-06</u>

Job Specific

End Date: <u>07-31-07</u> Q Standing /General

(Shaded areas 1 through 8 to be completed by requestor/initiator) Revised End Date:

4. Bldg: 911A 1. Initiator: Raymond Karol 2. Life #:15065 3. Phone: 5272

- 5. Job Location(s): Posted High Radiation Primary Beam Areas in Building 912 (Switchyard, Target Caves) and High Radiation Storage Areas.
- 6. Job Description (Attach sheets as needed): Routine Entry for Inspections, Data Collection, Tours, and Routine Work Activities Performed by a System Specialist.
- 7. Historical/Other Concerns: Exposure Rates > 1 R/hr and Localized Contamination Areas May Exist Following Operations with High Intensity Protons Near Target Stations.
- 9. Conditions that will void RWP: None

9. Conditions that will void RWP: None				
10. Job Review:	11. Estimated Dose:	12. Attachments:	13. Training Requirements:	
# Pre-Job Review Q Pre-Job Briefing Q ALARA Review Q Summary/Closeout Work Control Coordinator to Consult with Building Manager and/or Supervisor when assigning tasks. All work performed in Radiation Fields > 100 mRem/hr, notify Health Physics x-4660.	Highest Individual:mRem Q Per Job # Per Entry Collective:400mRem # RWP Total Q Per Entry	# Radiological Survey Form Posted at entrance to area Q Technical Work Document # Other: Pre-Job Review C-A OPM-ATT 9.5.11 See SI (1) Q Not Applicable	# Radiation Worker I (RWT 002) Q Contamination (RWT 300, 300A) Q Benchtop/Dispersibles (RWT 500) Q Benchtop/Dispersibles (RWT 500) # Other: C-A Access or Fixed Target User Training See SI (2) Q Not Applicable	
14. Work Controls:	15. Protective Equipment:	16. Dosimetry:	17. Check Out Instructions:	
# Facility Support Coverage See SI (3) Q Intermittent Q Continuous # Hold Points See SI (4) # Air Monitoring Q Shielding # Other: See SI (5)	Q Gloves Q Shoe Covers Q Coveralls Q Head Cover Q Red Trim Lab Coat Q Respirator Q Other: # Not Applicable	# TLD # Self Reading Dosimeter # Digital # Alarming Dosimeter (Dose Alarm Setpoint = 18 mrem)	Q Bioassay Q Whole Body Count Q Urine Sample Q Pre-Job Q Post-Job Q Contamination Check Q Personnel Frisk Q PCM # Activation check An Activation Check is Required for All Materials Removed From These Primary Beam Areas. Read and Follow All Postings.	

- 18. Special Instructions (SI): (Including Facility Specific Training)
- (1) Follow Guidance in OPM 9.5.11, C-A Procedure for Entry to Posted High Radiation Areas.
- (2) Visitors may be escorted by a trained and authorized C-A escort in accordance with C-A OPM 2.16.
- (3) When work is to be performed in Radiation Fields > 100 mR hr⁻¹, notify Health Physics prior to entry. Only one notification per job is required.
- (4) Hold Point #1: No single entry shall result in more than 20 mR per person. Multiple entries for one job shall be planned so that they do not result in greater than 20 mR per person or a Job-Specific RWP is required. Hold Point #2: This RWP is not for work in Radiation Fields > 1000 mR hr⁻¹, in posted Contamination Areas, Work with the potential to disperse or generate radioactive contamination such as Cutting, Grinding and Drilling, Handling or exposure to tritiated water, or unapproved alterations of radiation barriers.

Review appropriate radiological survey prior to commencing work.

19. Signatures Approvals:	Department	Life Number	Date
Facility Support Representative or Designee: Paul Bergh	RCD	19773	
Other (Department Specific): Edward T. Lessard	C-A	14255	
20. Close-Out Signature (FS Representative):			